

- 1) Make sure the surface to be covered with slatwall is flat - with no protrusions. A.
- 2) Determine the placement of the lower most slatwall profile and then, using a Level, mark a line across the entire length of the surface to be mounted.  
NOTE: Double check to make sure that the total number of slatwall profiles will fit onto the surface including top trim. (i.e. 6 Profiles x 6" + 1" = 37")
- 3) Place the hidden fastener trim onto the surface with the bottom aligned with the level line and attach with screws. (shown in figure A) NOTE: Trim must be mounted straight and level. Do not space screws greater than 16" apart and use maximum size #10 pan head screw. Screws must be centered with the small groove on the trim. Pre-drill if necessary.
- 4) Place the lower slatwall profile onto the trim section from step #3 making sure it is seated (adjust trim if necessary - Trim and slatwall must fit properly before continuing).
- 5) Place the next Hidden Fastener Slatwall profile onto the profile from step #4. REPEAT until all slatwall profiles are installed.
- 6) Place a piece of Hidden Fastener Trim onto the upper most slatwall profile flange (place trim as shown in figure E) NOTE: a small amount of adhesive may be placed on the top flange to help hold the trim in place. Trim on top is for decorative purposes only and is optional.



3" Hidden Fastener interlock

