

1" o/c Plastic Installation Guide

1) Make sure the surface to be covered with slatwall is flat - with no protrusions.

2) Determine the placement of the lower most slatwall profile and then, using a Level, mark a line across the entire length of the surface to be mounted. NOTE: Double check to make sure that the total number of slatwall profiles will fit onto the surface. (i.e. 6 Profiles x 6" = 36")

3) Place the first 6" slatwall piece onto the surface with the bottom aligned with the level line and attach with screws. Do not space screws greater than 16" apart and use maximum size #10 pan head screw. Screws must be centered. Pre-drill if necessary but do not countersink

4) Place the next Slatwall profile onto the profile from step #3. REPEAT until all slatwall profiles are installed.

